



PUMP HOLDER

Remove bolts:

Use bolts provided with your bike. Unscrew the bolts from the frame. Ensure the threads on the mounting rivets are clean of debris, paint and metal chips.

Line-up the bracket:

Place the bracket on the frame with mounting holes lined up with the mounting rivets on the frame.

Installing bolts:

Put a light layer of grease on the bolt threads. Whilst holding the bracket in proper position, hand-tighten the bolts into the mounting rivets. Be careful not to cross-thread the bolts.

Tighten:

Tighten the bolts with a 4mm Allen Wrench.

If using also using a bottle cage in the same position as the pump bracket, just position the pump bracket first and then the bottle cage on top of that, then use the bolts to screw through both.

