

PRO

BIKE TOOL

CHAIN LINK PLIERS

- 1. Locate master link of chain. The master link will be slightly wider than the others in the chain and have a small clip within it.**
- 2. Take tension off the chain.**
- 3. Insert the tips of the pliers into the links either side of the master link and squeeze handles to compress and separate the link. Remove chain.**
- 4. Assemble new chain and master link. Insert tips of the pliers into the links either side of the master link and pull handles apart until the link is locked in position**