

PRO

BIKE TOOL

ADJUSTABLE TORQUE WRENCH

- Consult bike manufacturer handbook for required Nm settings for bike parts e.g handlebar, seat post or refer to writing showing Nm setting on bike part on the bike
- Use a 6mm Allen / hex wrench to adjust the circular dial to set the desired torque.
- Withdraw the bit set by unscrewing the cap at the end of the tool and select the required tool bit.
- Insert the tool bit into the drive of the tool.
- Tighten the relevant bolt by applying a clockwise action. The torque wrench will continue to 'click-out' once the torque is reached, this ensures a bolt cannot accidentally be over torqued.

